ERROR CODIFICATION

Error code	Description	Potential failure	What to do!
Er 03 and "bip,bip sound"	Touch constantly used - Fingertouch switches-off after 10s.	Water or pan or cutlery on the glass over the touchcontrol.	Cleaning the glass surface in the area of the fingertouches or removing the pot.
Er12	Fingertouch switches-off after 10s.	Short circuit in the 5V power relays or mass.	Replace the Touch Control.
Er13	Fingertouch switches-off after 60s.	Touch Control is defect.	Replace the Touch Control.
Er21	Fingertouch cuts-off after the power setting.	The temperature of the environment of the electronic devices is too high.	Cool down the hob & check if the air-inlet of the fan is free.
Er22	Fingertouch switches-off after 3.5s - 7s.	Court-circuit or interruption is the sensor analysis.	Replace the Touch Control.
Er25	The secondary voltage is too high (primary> 300V). The Touch Control switches-off after 1s and a beep is emitted.	The touch Control is badly connected to the network.	Reconnect correctly the hob.
Er36	The NTC is out of tolerance (<200mV or> 4.9V). The Touch Control is off.	Short circuit at NTC.	Replace the Touch Control.
Er39	Er39 blinking.	Error of software programmation	Replace the Touch Control.
U4	U 4 blinking.	Hob connected on 400V network.	Disconnect the hob from the network and connect the hob right.